



graphics & background installation instructions:

1) be in a well ventilated area.

2) clean the plastic with lacquer thinner.

yes... new plastic does need to be cleaned!

be careful not to get lacquer thinner on anything but the plastic.

if your kit contains a tank decal, drain tank and ventilate for

3 days with the cap off. wait 2 days after install before refilling.

3) if your graphics came on a roll, cut them out with scissors.

4) lay the decal, image side down on a clean surface and peel back one inch of the backing sheet, then crease the backing flat to expose only one inch of adhesive.

5) place the decal in position to see if everything lines up.

if it doesnt line up, then remove it and try again.

6) remove the backing sheet one inch at a time while pressing it down with your thumb as you go.

7) if you get any bubbles, peel it back a little and continue the pressing procedure.

8) stand back in awe of your accomplishment.

take a photo and email it to us. info@ride ltd.com